



COMMERCIAL TYPE ELECTRICAL GRILL

USER MANUAL



MODELS: R57-R61-R63-R87-R89-RS94-RS95-R97-R83-R85-RS91



Producer: REMTA MAKİNA İTH. İHR. SAN. TİC. LTD. ŞTİ.

Producing Address: Akçaburgaz Mah. 4. Cad. 153. Sok. No:23 34522 Esenyurt - İstanbul
+90 212 886 27 11 • info@remta.com.tr • www.remta.com.tr

1. PRESENTATION

Dear user;

Our best thanks to you about you to choose our product and trust in us. Our products are used in lots of domestic cities like your choice. Our product is manufactured according to the standard rules. We kindly remind that you to read the user manual carefully for having the best performance against your expectations from the product and using for long time and be sure the other users read it, too. Please care about the rules written below before calling the service.

2. WARNINGS

Please read this manual carefully and be sure the other users read it, before the product is installed and operated for first. The product will be out of warranty if you operate the device without reading the user manual. The user manual should be written carefully to install, use and the maintenance of the product that you have bought. The electrical circuit that you will plug in your product, should be suitable for the legislations. The faults are in your responsibility which are occurred by your electrical circuit. Please call the authorized service to have more information about the subjects that you have doubts or misunderstand. We wish you to have the best performance from the product. You will be charged when you want service next to you about this product.

3. DESCRIPTION AND PURPOSE OF THE PRODUCT

The device is produced to cook the food on the grill surfaces to serve cooked food which are used in the industrial kitchen services (collective food services, restaurants, touristic places, buffets and etc.)

4. SAFETY DETAILS

- The device works with 220-230 Volt ~ 50-60 Hz electricity.
- If the electrical cable is damaged please contact with the service.
- The device should be switched off before plugged into the electricity.
- The all flammable solid and liquid materials (cloth, alcohol kinds, petrochemical materials, wooden materials, plastic materials and curtain) should be removed from the area that the device is operated.
- Do not clean the product under flowed and pressured water.
- The device can be used together with our other products in the same product serie. There has to be at least 30 cm between the each product.
- The device should be located and operated in a suitable for legislation and well aired place. Please check the instructions before locating and operating the device.
- The device is produced to use for industrial purposes and should be used by the well educated person.
- Noone should try to fix the device except the producer and the authorized service.
- If any flame occurs next to the device in the close location, please shut down the gas valves and the circuit breaker with out any panic. Use fire extinguisher. Never use water to extinguish the flame.
- The device should be plugged into the grounded socket out. Be sure that you have grounded line in your electricity circuit.
- All user should read the user manual.
- Keep away from the children.
- Do not use the device out its main purpose.
- Do not close the air flow holes of the device.
- The device should be located on a non-flammable surface.
- Do not operate it next to the hot machines.
- It has to be operated in a well aired place.
- Do not operate it under the sunlight directly.
- Please use heat resistant glove against its hot surfaces.

5. USING THE DEVICE

5.1. FIRST USE:

- Unpack the device from its box and check if it is damaged or not. Do not operate it if it is damaged..
- Take out the protection bands if there is.
- Clean well and carefully the parts of the device which touch directly to the food. Clean the oil with a cloth on the surface of the grill. Operate the device and burn residual oil.
- For the first use, some smoke can be seen. That smoke comes from the isolation material and that is so normal and usual event for this device.
- Lubricate the cooking surfaces after cleaning it otherwise it can be oxidated and the device should be out of warranty.
- Glass grill surfaces can be cleaned with a wet cloth.

5.2. USAGE:

- Plug in the device to the electricity socket out.
- Turn on the on / off switch (some models have)
- Set the thermostat as 250°C. It takes time about 40 minutes according to the model capacity.
- The thermostat indicator light turns off when it reaches to the cooking temperature and you can cook at this temperature.
- If the heat is not enough to cook, please set the thermostat higher value.
- The thermostat can be set as 150°C after cooking ends to save energy.
- Please switch off the thermostat after the service ends.
- Please plug out the device from the electricity socket out when it is out of use.
- Cooking surfaces should be cleaned very well after end of the use. Otherwise, dirty layers and hygienic problems can occur on the cooking surfaces.
- Please plug out the device from the electricity socket out when it is out of use.
- The device should be located on a flat surface.
- Do not hit the grill glass with a hard tool while the glass models are in use. The broken parts by impact will be out of warranty.

5.3. CLEANING:

- Plug out the device from the electricity socket before cleaning.
- The cooking surfaces should be cleaned very well after every use.
- The cooking surface should be lubricated with a fresh oil after it cleaned.
- Do not flow water inside of the device. Clean the main body with a wet cloth.
- Do not clean the main body under flow water.
- The oil drop holder should be cleaned.
- The device should be cleaned well and repacked if it will be out of use for a long time.

5.4. CARRYING AND MOVING

- Plug out the device from the electricity socket before carrying.
- It can be carried by human power.
- Do not bump or drop the device while you carry it.

5.5. MONTAGE:

- The under set desk should be parallel with the ground and have adjustable legs when the device is use on it.
- The electricity circuit should be checked by authorized person and has to be connected to the circuit breaker that located at least 170 cm height.
- The electricity circuit should have a leakage current breaker as 30 mA.
- The device should be used with grounded electricity circuit.

5.6. EFFICIENCY USE

- Switch off the device when it is out of use.
- Always keep the device clean.
- Please obey the directives written in the user manual.
- At 24 °C, you can have the best performance from the device.
- The device can work between -5 and +40 °C.

6. CLEANING AND MAINTENANCE

6.1. CLEANING:

- Clean the out surface with a sponge via using dish detergent and dry it out after every end of service beginning the first use.
- Do not use nitric acid or any kind of CHEMICAL MATERIALS to clean the device.

6.2. MAINTENANCE:

- Before any maintenance plug out the device from the electricity socket.
- Worn off parts should be replaced with the original exparts.
- The periodical maintenance should be done by the user.
- We recommend to maintenance for about per every 2 months according to the using frequency.
- It will be charged to user for maintenance even the device is warranty.

6.3. LIFE OF THE DEVICE

The life of the device is about 10 years if it is used according to the recommendations in the user manual.

6.4. FAULTS AND FAULT SOLUTIONS

1- The device is connected to the electricity socket out but it is not working!

- Check the main circuit breaker,
- Check the electric cable of the device,
- Check the thermostat and the on / off switch,
- If the problem still continuous please call the authorized service.

Do not struggle to fix it by your self.

6.5. SERVICE AND EXPART POINT

REMTA MAKİNA İTH. İHR. SAN. ve TİC. LTD. ŞTİ.

Adres: Akçaburgaz Mah. 4. Cad. 153. Sok. No:23 Esenyurt / İstanbul

Tel: +90 212 886 27 11

servis@remta.com.tr • www.remta.com.tr

You can find all coomunication information about our services in the link below.

www.remta.com.tr/yetkili-servisler

7. TECHNICAL PROPERTIES AND THE LABELS

KOD Code	ÜRÜN ÖLÇÜSÜ Product Dimensions	AĞIRLIK Weight	GÜÇ Power
R61	315*570*200mm	14 kg	2000 W
R63	420*475*210mm	17,5 kg	2000 W
R87	510*500*220mm	22,5 kg	2000 W
R89	700*510*220mm	34 kg	2800 W
RS94	510*500*220mm	22,5 kg	2000 W
RS95	700*510*220mm	34 kg	2800 W
R97	310*570*200mm	11 kg	2000 W
R83	505*505*220mm	15 kg	2000 W
R85	700*510*220mm	20,5 kg	2800 W
RS91	1030*530*210mm	29 kg	3400 W
R57	600*420*200mm	7 kg	1700 W

ELEKTRİKLİ İZGARA		CE
ÜRÜN KODU: R89 MODEL: 70 CM DÖKÜM İZGARA / 70 CM CAST IRON GRILL		
VOLTAJ / Voltage: 220 - 230 V 50-60 Hz AKIM / Nominal Current: 12,5 A GÜÇ / Power: 2800W ÜRÜN SINIFI / Product Class: I / IP 20 AĞIRLIK / Weight: 34 KG EBAT / Dimensions: 700x510x220 mm		
REMTA MAKİNA • AKÇABURGAZ MH. 4 CD 153.SK. NO:23 ESENİYURT / İSTANBUL / TURKEY • TEL: +90 212 886 27 11		www.remta.com.tr
SERİ NO:	MADE IN TURKEY	



HOT SURFACE

WARNING! GROUNDED ELECTICITY CIRCUIT

8. PART DESCRIPTION

